

Table:

Sample being purified:	PCR of pA15A from 2015-04-18
Concentration:	999.9 ng/ μ L
Additional info: - (did it go okay? did anything problematic happen?)	

Preparations:

- Find your PCR or digest sample to purify it.

Procedure:

- 1) See QIAGEN kit protocol.

Assembled 2015 by Olya Spassibojko. Adapted from 2012. Source: QIAGEN company